


MAKE SHRUB HOLE TWICE THE DIAMETER OF THE ROOTBALL

PRIOR TO MULCHING LIGHTLY TAMP BACKFILLED SUB-SOIL AND PLANTING SOIL AROUND THE ROOTBALL TO BRACE SHRUB. DO NOT OVER COMPACT. WHEN THE SHRUB HOLE HAS BEEN BACKFILLED, POUR WATER AROUND THE ROOTBALL TO SETTLE THE SOIL.

FIN. GRADE

300

450



PLACE TOP OF ROOTBALL SLIGHTLY HIGHER TO ALLOW FOR SETTLEMENT. FORM SAUCER AROUND ROOT BALL WITH PLANTING SOIL AND WATER AS NECESSARY.

50MM DEPTH OF MULCH (AS SPECIFIED)

SOIL DEPTH REQUIREMENTS:
300MM: PLANTING SOIL OR AS PER SPECIFICATION.

750MM UNCOMPACTED SOIL AROUND THE ROOTBALL.

COMPOST AMENDED TOPSOIL AS PER SPECIFICATIONS

SCARIFIED SUB-SOIL AS PER SPECIFICATIONS.

BACKFILL WITH LOOSENED SUB-SOIL.

ROUGHEN BOTTOM AND SIDES OF SHRUB HOLE

BOTTOM OF ROOTBALL RESTS ON MOUND OF COMPACTED SUB-SOIL OR COMPACTED SUBGRADE, SUITED TO SITE CONDITIONS.

COMPACTED SUBGRADE AND/OR UNDISTURBED EXISTING SOIL

2

D.1

DECIDUOUS SHRUB IN PLANTING BED W/ COMPOST AMENDED TOPSOIL

1: 25